



MAINTENANCE MANUAL

FOR BATHROOM ACCESSORIES BY BISK S.A.

No.	Product	Maintenance instructions
1.	BINS (STEEL)	Do not clean with aggressive and/or abrasive agents. Clean with water and soap and wipe dry. It is inadvisable to place the bin near a toilet bowl or urinal (urine drops stain steel surface permanently).
2.	SOAP DISPENSERS (STEEL AND PLASTIC)	Do not clean with aggressive and/or abrasive agents. Clean with water and soap and wipe dry. Make sure that the soap inside the dispenser does not crystallize due to not using the dispenser for a long period of time. Dried soap can clog the outlet or the pump. If this should happen, the whole system should be cleaned with hot water by repeatedly pressing the distributor's pump. Make sure that the soap used is the right one for the given dispenser (liquid, foam, etc.).
3.	PAPER TOWEL DISPENSERS (STEEL AND PLASTIC)	Clean with water and soap and wipe dry. Do not clean with aggressive and/or abrasive agents.
4.	HAND DRYERS (STEEL AND PLASTIC)	The dryer should be fitted and used according to the instructions and guarantee terms as enclosed to the product. In case of a break-down, the seller or distributor should be contacted. For product maintenance, it should be unplugged, then wiped with a damp cloth and dried. Do not use aggressive and/or abrasive agents.
5.	TOILET BRUSHES (STEEL)	Do not clean with aggressive and/or abrasive agents. Clean with water and soap and wipe dry. It is inadvisable to place the bin near a toilet bowl or urinal (urine drops stain steel surface permanently). Having disinfected/cleaned the draining container and the brush, the product should be rinsed with running water. Do not leave water or cleaning and/or caustic agents inside the draining container.
6.	MIXERS AND FAUCETS	Follow the instructions as given in the fitting and maintenance manual.
7.	METAL BATHROOM ACCESSORIES AND SHOWER SETS	Do not use aggressive and/or abrasive agents. Clean with water and soap and wipe dry or use agents meant for cleaning such products, as specified in the user manual.
8.	BATHROOM ACCESSORIES COLLECTIONS (CONTAINING WOOD)	Wood should be cleaned and frequently treated with woodwork maintenance agents. Chromed and 'brushed nickel' elements should be cleaned with water and soap, then wiped dry. Do not clean with aggressive and/or abrasive agents.
9.	"PRO" ACCESSORIES	Clean with soft damp cloth, preferably soaked with washing-up detergent. Wipe dry. Do not use chlorine-, acid-, or nitro-solvent-based agents, or abrasives.
10.	ALL PLASTIC PRODUCTS	Do not clean with aggressive and/or abrasive agents. Clean with water and soap only, using soft cloth, then wipe dry.
11.	ALL OTHER CHROMED METAL AND STAINLESS STEEL PRODUCTS	Do not clean with aggressive and/or abrasive agents. Clean with water and soap, then wipe dry.